

- (a) Insert the U-Bolts into the outdoor sensor mounting bracket and hand tighten the nuts.
- (b) Tighten the nuts to fit the size of your mounting pole
- (c) Insert the outdoor sensor and U-Bolt assembly onto the mounting pole.
- (d) Tighten the U-Bolts around the pole with an adjustable wrench. Make sure the outdoor sensor is level.

